



SAFETY STORAGE DEPOTS

Approved for the storage of water-endangering substances

These compact storage depots have been specially developed for drum and KTC/IBC storage on the basis of our practically-proven safety storehouses. Due to their generous dimensions it is possible to store 200 liter drums directly above the base sump tray or also on euro- or chemical pallets.

There is also sufficient space available for storing large containers (KTC/IBC).



**SLH 1,5 x 1,5,
Article no. H61-2121-B**



**SLH 1 x 1,
Article no. H61-2120-B**

Special container construction:

- ◆ Made from specially profiled galvanized sheet steel
- ◆ Reinforced roof and base profile frames
- ◆ Circumferential splash protection made from sheet steel, except in door area
- ◆ 1-wing door, W x H (mm) = 1300 x 1580, lockable with safety lock
- ◆ Built-in weather-protected ventilation slots in door and sidewalls

Base sump tray:

- ◆ Made from 3 mm **fire galvanized** sheet steel, as per WHG - **Ü-sign according to StawaR**
- ◆ Galvanized grid as support level
- ◆ Ground clearance 100 mm, for model SLH 1,5 x 1,5 KTC 60 mm



**SLH 1,5 x 1,5 KTC,
Article no. H61-2122-B**



**SLH 1,5 x 1,5 KTC,
thermally insulated version,
price on request!**

Model	SLH 1 x 1	SLH 1,5 x 1,5	SLH 1,5 x 1,5 KTC
External dimensions W x D x H (mm)	1700 x 1300 x 2015	1700 x 1700 x 2015	1700 x 1700 x 2250
Internal dimensions W x D x H (mm)	1570 x 1170 x 1650	1570 x 1570 x 1650	1570 x 1570 x 1650
Sump capacity (l)	220	220	1000
Capacity	2 x 200 liter drum	4 x 200 liter drum	1 x KTC
Weight (kg)	310	390	430
Article no., galvanized	H61-2120-B	H61-2121-B	H61-2122-B
Article no., galvanized, exterior painted	H61-6120-B	H61-6121-B	H61-6122-B



SAFETY STORAGE DEPOTS WITH NATURAL VENTILATION

Approved for the passive storage of flammable liquids

Special container construction:

- ◆ Made from specially profiled galvanized sheet steel
- ◆ Reinforced roof and base profile frames
- ◆ Circumferential splash protection made from sheet steel, except in door area
- ◆ 1-wing door, W x H (mm) = 1300 x 1580, lockable with safety lock
- ◆ Built-in weather-protected ventilation slots in door and sidewalls

Base sump tray:

- ◆ Made from 3 mm **fire galvanized** sheet steel, as per WHG - **Ü-sign according to StawaR**
- ◆ Galvanized grid as support level
- ◆ Ground clearance 100 mm, for model SLH-NB 1,5 x 1,5 KTC 60 mm

Natural ventilation:

- ◆ The legally required 0.4-fold minimum air exchange rate is achieved by the continuous ventilation slots directly above the base sump tray and the ventilation slots in the door and side walls.
- ◆ With ground connection for the avoidance of hazardous electrostatic charges (for Ex-zone 2).



**SLH-NB 1 x 1,
Article no. H61-1110-A**



**SLH-NB 1 x 1,
Article no. H61-1110-A**



**SLH-NB 1 x 1,
Article no. H61-1110-A**

Rate of air exchange has been tested and approved in accordance with the latest requirements of DIBt Berlin!

Model	SLH-NB 1 x 1	SLH-NB 1,5 x 1,5	SLH-NB 1,5 x 1,5 KTC
External dimensions W x D x H (mm)	1700 x 1300 x 2160	1700 x 1700 x 2160	1700 x 1700 x 2405
Internal dimensions W x D x H (mm)	1570 x 1170 x 1790	1570 x 1570 x 1790	1570 x 1570 x 1790
Sump capacity (l)	220	220	1000
Capacity	2 x 200 liter drum	4 x 200 liter drum	1 x KTC
Weight (kg)	330	420	460
Article no., galvanized	H61-1110-A	H61-1111-A	H61-1112-A
Article no., galvanized, exterior painted	H61-2110-A	H61-2111-A	H61-2112-A